## 9. Clear Memory Mode

## **A: OPERATION**

Refer to SUBARU SELECT MONITOR for information about how to clear diagnostic trouble codes (DTC). <Ref. to ABS-16, Subaru Select Monitor.>

## **CLEAR MEMORY MODE**

ABS (DIAGNOSTICS)

MEMO: