

## 10.Reduction Driven Gear (4AT with VTD)

### A: NOTE

For removal, installation and inspection work, refer to "4AT" section. <Ref. to 4AT-97, Reduction Driven Gear.>