


ELECTRICAL COMPONENTS LOCATION

CRUISE CONTROL SYSTEM (DIAGNOSTICS)

3. Electrical Components Location

A: LOCATION



(1) Cruise control command switch
(2) Cruise control main switch
(Built-in cruise indicator light)

(3) Clutch switch
(4) Stop light and brake switch

(5) Engine control module (ECM)
(6) Cruise set indicator light