

10.Rear Accessory Power Socket

A: REMOVAL

- 1) Disconnect ground cable from battery.
- 2) Remove console box. <Ref. to EI-36, REMOVAL, Console Box.>
- 3) Disconnect harness connectors and remove rear accessory power socket from console box.

B: INSTALLATION

Install in the reverse order of removal.

REAR ACCESSORY POWER SOCKET

ENTERTAINMENT

MEMO: