1. Engine Trouble in General

A, B and C shown in the RANK of table refer to the possibility of reason for the trouble in order ("Very often" to "Rarely"). A: Very often B: Sometimes C : Rarely

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
Engine will not start.			
1) Starter does not turn.	Starter	Defective battery-to-starter harness	В
		Defective starter switch	С
		Defective inhibitor switch or neutral switch	С
		Defective starter	В
	Battery	Poor terminal connection	A
		Run-down battery	Α
		Defective charging system	В
	Friction	Seizure of crankshaft and connecting rod bearing	С
		Seized camshaft	С
		Seized or stuck piston and cylinder	С
2) Initial combustion does	Starter	Defective starter	С
not occur.	• Fuel injection system <re< td=""><td>ef. to 2-7 On-Board Diagnostics II System></td><td>А</td></re<>	ef. to 2-7 On-Board Diagnostics II System>	А
	• Fuel line	Defective fuel pump and relay	А
		Lack of or insufficient fuel	В
	Belt	Defective	В
		Defective timing	В
	 Compression 	Incorrect valve clearance	С
		 Loosened spark plugs or defective gasket 	С
		Loosened cylinder head bolts or defective gasket	С
		Improper valve seating	С
		Defective valve stem	С
		Worn or broken valve spring	В
		Worn or stuck piston rings, cylinder and piston	С
		Incorrect valve timing	В
		• Improper engine oil (low viscosity)	В
3) Initial combustion	• Fuel injection system <re< td=""><td>ef. to 2-7 On-Board Diagnostics II System></td><td>А</td></re<>	ef. to 2-7 On-Board Diagnostics II System>	А
occurs.	Intake system	Defective intake manifold gasket	В
•		Defective throttle body gasket	В
	• Fuel line	Defective fuel pump and relay	С
		Clogged fuel line	С
		Lack of/or insufficient fuel	В
	Belt	Defective	В
		Defective timing	В
	Compression	Incorrect valve clearance	С
		Loosened spark plugs or defective gasket	С
		Loosened cylinder head bolts or defective gasket	С
		Improper valve seating	С
		Defective valve stem	С
		Worn or broken valve spring	В
		Worn or stuck piston rings, cylinder and piston	С
		Incorrect valve timing	В
		Improper engine oil (low viscosity)	В

DIAGNOSTICS

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
4) Engine stalls after initial combustion.	• Fuel injection system <re< td=""><td>f. to 2-7 On-Board Diagnostics II System></td><td>А</td></re<>	f. to 2-7 On-Board Diagnostics II System>	А
	Intake system	Loosened or cracked intake duct	В
		Loosened or cracked PCV hose	С
		Loosened or cracked vacuum hose	С
		Defective intake manifold gasket	В
		Defective throttle body gasket	В
		Dirty air cleaner element	С
	• Fuel line	Clogged fuel line	С
		Lack of or insufficient fuel	В
	Belt	Defective	В
		Defective timing	В
	Compression	Incorrect valve clearance	С
		Loosened spark plugs or defective gasket	С
		Loosened cylinder head bolts or defective gasket	С
		Improper valve seating	С
		Defective valve stem	С
		Worn or broken valve spring	В
		Worn or stuck piston rings, cylinder and piston	С
		Incorrect valve timing	В
		Improper engine oil (low viscosity)	В
2. Rough idle and engine	• Fuel injection system <re< td=""><td>f. to 2-7 On-Board Diagnostics II System></td><td>A</td></re<>	f. to 2-7 On-Board Diagnostics II System>	A
stall	Intake system	Loosened or cracked intake duct	А
stall		Loosened or cracked PCV hose	А
		Loosened or cracked vacuum hose	A
		Defective intake manifold gasket	В
		Defective throttle body gasket	В
		Defective PCV valve	С
		Loosened oil filler cap	В
		Dirty air cleaner element	С
	• Fuel line	Defective fuel pump and relay	С
		Clogged fuel line	С
		Lack of/or insufficient fuel	В
	Belt	Defective timing	С
	Compression	Incorrect valve clearance	В
		Loosened spark plugs or defective gasket	В
		Loosened cylinder head bolts or defective gasket	В
		Improper valve seating	В
		Defective valve stem	С
		Worn or broken valve spring	В
		Worn or stuck piston rings, cylinder and piston	В
		Incorrect valve timing	А
		Improper engine oil (low viscosity)	В
	Lubrication system	Incorrect oil pressure	В
	,	Defective rocker cover gasket	С
	Cooling system	Overheating	C
	Others	Malfunction of evaporative emission control system	A
		Stuck or damaged throttle valve	В
		Accelerator cable out of adjustment	C

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
3. Low output, hesitation	• Fuel injection system <re< td=""><td>f. to 2-7 On-Board Diagnostics II System></td><td>А</td></re<>	f. to 2-7 On-Board Diagnostics II System>	А
and poor acceleration	Intake system	Loosened or cracked intake duct	А
		Loosened or cracked PCV hose	А
		Loosened or cracked vacuum hose	В
		Defective intake manifold gasket	В
		Defective throttle body gasket	В
		Defective PCV valve	В
		Loosened oil filler cap	В
		Dirty air cleaner element	A
	Fuel line	Defective fuel pump and relay	В
		Clogged fuel line	В
		Lack of/or insufficient fuel	C
	Belt	Defective timing	В
	Compression	Incorrect valve clearance	В
	Compression	Loosened spark plugs or defective gasket	В
		Loosened cylinder head bolts or defective gasket	В
		Improper valve seating	В
		Defective valve stem	C
		Worn or broken valve spring	В
			С
		Worn or stuck piston rings, cylinder and piston	
		Incorrect valve timing	A
		Improper engine oil (low viscosity)	В
	Lubrication system	Incorrect oil pressure	В
	Cooling system	• Overheating	С
		Over cooling	С
	Others	Malfunction of evaporative emission control system	A
4. Surging		ef. to 2-7 On-Board Diagnostics II System>	A
	• Intake system	Loosened or cracked intake duct	A
		Loosened or cracked PCV hose	A
		Loosened or cracked vacuum hose	A
		Defective intake manifold gasket	В
		Defective throttle body gasket	В
		Defective PCV valve	В
		Loosened oil filler cap	В
		Dirty air cleaner element	В
	• Fuel line	Defective fuel pump and relay	В
		Clogged fuel line	В
		Lack of/or insufficient fuel	С
	Belt	Defective timing	В
	Compression	Incorrect valve clearance	В
		Loosened spark plugs or defective gasket	С
		Loosened cylinder head bolts or defective gasket	С
		Improper valve seating	С
		Defective valve stem	C
		Worn or broken valve spring	C
		Worn or stuck piston rings, cylinder and piston	C
		Incorrect valve timing	A
		Improper engine oil (low viscosity)	В
	- Cooling ayatam		_
	Cooling system	• Overheating	В
	Others	Malfunction of evaporative emission control system	С

DIAGNOSTICS

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
5. Engine does not return to idle.	• Fuel injection system <re< td=""><td>ef. to 2-7 On-Board Diagnostics II System></td><td>Α</td></re<>	ef. to 2-7 On-Board Diagnostics II System>	Α
	 Intake system 	Loosened or cracked vacuum hose	Α
	Others	Stuck or damaged throttle valve	Α
		Accelerator cable out of adjustment	В
6. Dieseling (Run-on)	• Fuel injection system <re< td=""><td>ef. to 2-7 On-Board Diagnostics II System></td><td>Α</td></re<>	ef. to 2-7 On-Board Diagnostics II System>	Α
	 Cooling system 	Overheating	В
	Others	Accelerator cable out of adjustment	В
7. After burning in exhaust	• Fuel injection system <re< td=""><td>ef. to 2-7 On-Board Diagnostics II System></td><td>Α</td></re<>	ef. to 2-7 On-Board Diagnostics II System>	Α
system	Intake system	Loosened or cracked intake duct	С
		Loosened or cracked PCV hose	С
		Loosened or cracked vacuum hose	В
		Defective PCV valve	В
		Loosened oil filler cap	С
	Belt	Defective timing	В
	Compression	Incorrect valve clearance	В
		Loosened spark plugs or defective gasket	С
		Loosened cylinder head bolts or defective gasket	С
		Improper valve seating	В
		Defective valve stem	С
		Worn or broken valve spring	С
		Worn or stuck piston rings, cylinder and piston	С
		Incorrect valve timing	Α
	Lubrication system	Incorrect oil pressure	С
	Cooling system	Over cooling	С
	Others	Malfunction of evaporative emission control system	С
8. Knocking	• Fuel injection system <re< td=""><td>ef. to 2-7 On-Board Diagnostics II System></td><td>А</td></re<>	ef. to 2-7 On-Board Diagnostics II System>	А
. Excessive engine oil	Intake system	Loosened oil filler cap	В
	Belt	Defective timing	В
	Compression	Incorrect valve clearance	С
		Incorrect valve timing	В
	 Cooling system 	Overheating	Α
9. Excessive engine oil	Intake system	Loosened or cracked PCV hose	Α
consumption		Defective PCV valve	В
		Loosened oil filler cap	С
	 Compression 	Defective valve stem	Α
		Worn or stuck piston rings, cylinder and piston	Α
	 Lubrication system 	Loosened oil pump attaching bolts and defective gasket	В
		Defective oil filter seal	В
		Defective crankshaft oil seal	В
		Defective rocker cover gasket	В
		Loosened oil drain plug or defective gasket	В
		Loosened oil pan fitting bolts or defective oil pan	В

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
10. Excessive fuel con-	• Fuel injection system <ref. 2-7="" diagnostics="" ii="" on-board="" system="" to=""></ref.>		Α
sumption	 Intake system 	Dirty air cleaner element	Α
	Belt	Defective timing	В
	Compression	Incorrect valve clearance	В
		Loosened spark plugs or defective gasket	С
		Loosened cylinder head bolts or defective gasket	С
		Improper valve seating	В
		Defective valve stem	С
		Worn or broken spring	С
		Worn or stuck piston rings, cylinder and piston	В
		Incorrect valve timing	В
	 Lubrication system 	Incorrect oil pressure	С
	 Cooling system 	Over cooling	С
	Others	Accelerator cable out of adjustment	В