1. Supplemental Restraint System "Airbag" AIRBAG

A: PRECAUTION

Airbag system wiring harness is routed near the steering wheel, steering shaft and column.

WARNING:

• All airbag system wiring harness and connectors are yellow. Do not use electrical test equipment on these circuit.

• Be careful not to damage airbag system wiring harness when servicing the steering wheel, steering shaft and column.