

# Engine Control Module (ECM) I/O Signal

CRUISE CONTROL SYSTEM (DIAGNOSTICS)

---

## 4. Engine Control Module (ECM) I/O Signal

### A: WIRING DIAGRAM

<Ref. to WI-90, NON-TURBO MODEL, WIRING DIAGRAM, Cruise Control System.>

<Ref. to WI-93, TURBO MODEL, WIRING DIAGRAM, Cruise Control System.>