

16.Rear Window Defogger System

A: WIRING DIAGRAM

1. REAR WINDOW DEFOGGER

<Ref. to WI-133, WIRING DIAGRAM, Rear Defogger System.>

B: INSPECTION

Symptom	Repair order
Rear window defogger does not operate.	<ol style="list-style-type: none">1. Fuse (M/B No. 1) (F/B No. 17)2. Rear defogger relay3. Rear defogger timer4. Defogger switch5. Rear defogger condenser6. Defogger wire7. Wiring harness