


\*1 : LHD MODEL : RW  
RHD MODEL : R



- MAIN FUSE BOX (M/B)
- B: (B143)
  - C: (F35)
  - E: (F36)
  - G: (B145)
  - H: (B186)

G: (B145) (BROWN)

H: (B186)

C: (F35) (BLUE)

B: (B143)

E: (F36)

1	2	3
4	5	6
7		

1		2	3
4	5	6	7
8			

1	2	3	4	5
6	7	8	9	10
11	12			

1	2	3	4		5	6	7	8	9
10	11	12	13	14	15	16	17	18	19
20									