

42. Bulkhead Wiring Harness (In Compartment) S903446

A: LOCATION S903446A13

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B30	24	★	C-1	D1	Front door cord LH
B31	7	★	C-1	AB1	SRS (Airbag) harness
B32	3	Black	B-2		Turn & hazard module
B36	24	Blue	B-2	i1	Instrument panel wiring harness
B37	16	★	B-2	i2	
B40	16	★	C-2		Data link connector
B41	2	★	B-2		Power window circuit breaker
B42	4	Blue	B-1		Power window relay
B43	6	Black	B-4		Illumination control module
B45	6	★	A-4	R53	Roof cord
B46	4	Green	B-1		Fuel pump relay
B47	6	Brown	B-1		Main relay
B48	4	Red	B-1		Front fog light relay
B50	4	★	B-1		Blower relay
B51	8	Blue	C-1		F/B
B52	12	Blue	C-1		
B53	6	★	B-2		Shield joint connector (AT)
B54	24	★	B-2		Transmission control module
B55	24	Gray	C-2		
B57	12	★	B-2		Shift lock control module (AT)
B61	8	★	B-1	F44	Front wiring harness
B62	20	★	B-1	F45	
B64	2	Black	B-2		Stop light switch
B65	4	Black	B-2		Stop & brake switch (With cruise control)
B68	5	Black	B-2		Cruise control sub switch
B69	4	★	C-2		Combination switch
B70	18	★	C-2		
B71	17	★	C-2		
B72	4	Blue	B-2		Ignition switch
B73	2	★	B-2		Key lock solenoid (AT)
B74	2	Black	B-2		Key warning switch
B75	2	Green	B-2	B76	Test mode connector
B76	2	Green	B-2	B75	
B79	14	Gray	C-3		Check connector
B81	1 × 2	★	B-2		Diagnosis terminal (Ground)
B82	6	Black	B-2		Diagnosis connector
B83	6	★	C-4		Shield joint connector (E/G)
B86	4	★	B-3		Blower motor resistor
B87	2	★	B-4		Blower motor
B88	4	Brown	B-3		Evaporator thermostwitch
B92	6	★	B-1		Door lock timer
B94	20	★	C-1		Cruise control module
B95	2	★	B-4		Diode (Daytime running light)
B96	10	★	B-4		Daytime running light control module
B97	10	Blue	B-4	R1	Rear wiring harness
B98	20	Black	B-4	R2	
B99	20	★	B-4	R3	

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B100	16	Blue	B-1	F2	Front wiring harness (With ABS model)
B101	24	★	B-4	D11	Front door cord RH
B102	5	★	B-4		Daytime running light relay
B103	4	Blue	B-4		Daytime running light hi-beam relay
B104	4	Red	B-4		Rear accessory power supply relay
B105	4	Blue	B-2		Starter interlock relay (MT)
B106	2	★	B-2		Clutch switch (MT)
B107	2	Blue	B-2		Clutch switch (Cruise control)
B108	8	★	B-1	F46	Front wiring harness
B112	2	★	B-2		Diode (Front fog light)
B116	4	Black	C-3		Select lever illumination light (AT)
B117	4	★	C-3		Parking position switch & shift lock solenoid (AT)
B118	2	★	C-3		CD player illumination light
B119	1	★	C-3		Front accessory power supply (Power)
B120	14	★	C-3		Radio
B121	1	★	B-3		Audio ground
B122	6	★	C-4		Sensor ground joint connector (E/G)
B125	1	Green	B-4	B126	Test mode connector
B126	1	Green	B-4	B125	
B134	35	★	B-3		Engine control module (2200 cc engine model)
B134	35	Black	B-3		Engine control module (2500 cc engine model)
B135	28	★	B-3		Engine control module (2200 cc engine model)
B135	28	Black	B-3		Engine control module (2500 cc engine model)
B136	30	★	B-3		Engine control module (2200 cc engine model)
B136	30	Black	B-3		Engine control module (2500 cc engine model)
B152	7	★	B-1		F/B
B158	12	★	B-1		F/B
B159	10	Gray	B-1		F/B
B160	6	Gray	C-1		Front fog light switch
B161	6	Brown	C-1		Cruise control main switch
B162	8	★	C-2	B163	Combination switch cord
B163	8	★	C-2	B162	Bulkhead wiring harness
B164	18	★	C-2	B165	Combination switch cord
B165	18	★	C-2	B164	Bulkhead wiring harness
B166	10	★	B-2		Key warning module
B167	3	★	C-3		Front accessory power supply (Ground)
B168	3	★	B-3		A/C switch
B169	6	★	B-3		Blower fan switch
B170	2	★	B-3		Mode control panel illumination light
B175	2	★	C-3		Ash tray illumi. light
B176	10	★	C-2		Keyless entry control module

★: Non-colored

