## 4. Engine Oil Filter

## A: REPLACEMENT

Refer to "LU" section for engine oil filter replacement. <Ref. to LU(H4DO)-27, Engine Oil Filter.>