

## General Diagnostic Table

CONTROL SYSTEMS

---

### 8. General Diagnostic Table

#### A: INSPECTION

Symptoms	Possible cause	Corrective action
Select lever	Starter does not run.	Adjust the select cable and inhibitor switch, or inspect the circuit.
	Back-up light does not illuminate.	Adjust the select cable and inhibitor switch, or inspect the circuit.
	AT shift lock system does not operate normally.	Adjust the select cable and inhibitor switch, or inspect the circuit.
	Manual mode can not be set.	Inspect the mode switch and select lever, or inspect the circuit.
	Up-shift is not engaged at manual mode.	Check the shift-up switch and circuit.
	Down-shift is not engaged at manual mode.	Check the shift-down switch and circuit.

# CONTINUOUSLY VARIABLE TRANSMISSION

# CVT

	Page
1. General Description .....	2
2. CVTF .....	34
3. Differential Gear Oil .....	39
4. AWD ON/OFF Switching Mode .....	43
5. Road Test .....	44
6. Stall Test .....	45
7. Time Lag Test .....	46
8. Secondary Pressure (Line Pressure) Test .....	47
9. Transfer Clutch Pressure Test .....	50
10. Automatic Transmission Assembly .....	56
11. Transmission Mounting System .....	79
12. Extension Case Oil Seal .....	83
13. Differential Side Retainer Oil Seal .....	85
14. Inhibitor Switch .....	90
15. Turbine Speed Sensor .....	97
16. Secondary Speed Sensor .....	99
17. Primary Speed Sensor .....	101
18. Secondary Pressure Sensor .....	104
19. Oil Pan and Strainer .....	106
20. Control Valve Body .....	110
21. Transmission Harness .....	124
22. Transmission Control Module (TCM) .....	136
23. CVTF Cooler (With Warmer Function) .....	138
24. Air Breather Hose .....	148
25. Drive Plate .....	150
26. Torque Converter Assembly .....	152
27. Preparation for Overhaul .....	154
28. Extension Case .....	156
29. Transfer Clutch .....	160
30. Transfer Driven Gear .....	174
31. Parking Pawl .....	177
32. Reduction Driven Gear .....	179
33. Transmission Control Device .....	187
34. Transmission Case .....	193
35. CVTF Filter .....	205
36. Reduction Drive Gear .....	206
37. Primary Pulley and Secondary Pulley .....	210
38. Variator Chain .....	230
39. Reverse Brake Assembly .....	231
40. Forward Clutch Assembly .....	246
41. Drive Pinion Shaft Assembly .....	265
42. Front Differential Assembly .....	294
43. Oil Pump Chain .....	312
44. Oil Pump .....	321
45. Converter Case .....	324
46. Diagnostics with Phenomenon .....	327