12.Clutch System

A: INSPECTION AND ADJUSTMENT

Refer to "CL" section for inspection and adjustment of clutch system. <Ref. to CL-23, INSPECTION, Clutch Pedal.> <Ref. to CL-23, ADJUSTMENT, Clutch Pedal.>