

## **Clear Memory Mode**

TIRE PRESSURE MONITORING SYSTEM (DIAGNOSTICS)

---

### **7. Clear Memory Mode**

#### **A: OPERATION**

For the operation procedure, refer to the “PC application help for Subaru Select Monitor”.