POWER ASSISTED SYSTEM (POWER STEERING) (DIAGNOSTICS)

9. Clear Memory Mode

A: OPERATION

• For detailed operation procedures, refer to "PC application help for Subaru Select Monitor".

• Before performing memory clear, check the current data, and if there are any data of DTC, trouble status information, overheating protection intervention history, IGN count from overheating protection and assist limit history, save them.