

### **8. Read Diagnostic Trouble Code (DTC)**

#### **A: OPERATION**

For operation procedures, refer to the “PC application help for Subaru Select Monitor”.

**NOTE:**

For details concerning DTCs, refer to List of Diagnostic Trouble Codes (DTC). <Ref. to AB(diag)-34, List of Diagnostic Trouble Code (DTC).>