

1. General Description

A: SPECIFICATION

Refer to "Body Repair Manual" for general description of body structure, reference points and reference dimensions.

INSTRUMENTATION/DRIVER INFO



	Page
1. General Description	2
2. Relay and Fuse	6
3. Combination Meter System	7
4. Multi-function Display (MFD) System	11
5. Combination Meter	17
6. Speedometer	20
7. Tachometer	21
8. Fuel Gauge	22
9. ECO Gauge	23
10. Multi-function Display (MFD)	24
11. Steering Switch	27