


Electrical Component Location

IMMOBILIZER (DIAGNOSTICS)

3. Electrical Component Location

A: LOCATION



IM-00393

(1) Antenna

(3) Body integrated unit

(5) Security control module (only for Canada models)

(2) Security indicator light (LED bulb)

(4) Transponder