







14. Cruise Control System

A: WIRING DIAGRAM



Cruise Control System

WIRING SYSTEM





WI-37826

Cruise Control System

WIRING SYSTEM

C/C-03







C/C-03



WI-34184

Cruise Control System

WIRING SYSTEM



A: (B134)

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	17
18	19	20	21	22	23	24	25	26	27
28	29	30	31	32		33	34		

C: (B136)

1	2	3	4	5	6					
7	8	9	10	11	12	13	14	15	16	
17	18	19	20	21	22	23	24	25	26	27
28	29	30		31	32	33	34	35		

WI-34185

