
6. Diagnostic Chart for On-board **Diagnostics System**

A: BASIC DIAGNOSTIC PROCEDURE



D: LIST OF TROUBLE CODE

1. TROUBLE CODE

Trouble code	ltem	Content of diagnosis	Abbr. (Select monitor)	Page
11	Duty solenoid A	Detects open or shorted drive circuit, as well as valve seizure.	PLDTY	<u>—</u>
12	Duty solenoid B	Detects open or shorted drive circuit, as well as valve seizure.	LUDTY	_
13	Shift solenoid 3	Detects open or shorted drive circuit, as well as valve seizure.	OVR	
14	Shift solenoid 2	Detects open or shorted drive circuit, as well as valve seizure.	SFT2	
15	Shift solenoid 1	Detects open or shorted drive circuit, as well as valve seizure.	SFT1	<u>-</u>
21	ATF temperature sensor	Detects open or shorted input signal circuit.	ATFT	_
22	Mass air flow signal	Detects open or shorted input signal circuit.	AFM	4
23	Engine speed signal	Detects open or shorted input signal circuit.	EREV	6
24	Duty solenoid C	Detects open or shorted drive circuit, as well as valve seizure.	4WDTY	
25	Torque control signal	Detects open or shorted input signal circuit.	то.ст	8
31	Throttle position sensor	Detects open or shorted input signal circuit.	THV	10
32	Vehicle speed sensor 1	Detects open or shorted input signal circuit.	VSP1	
33	Vehicle speed sensor 2	Detects open or shorted input signal circuit.	VSP2	