

Sun visors




To block out glare, swing down the visors. To use the sun visor at a side window, swing it down and move it sideways.

■ Vanity mirror (if equipped)



To use the vanity mirror, swing down the visor.

■ Vanity mirror with light (if equipped)



To use the vanity mirror, swing down the visor and open the cover. The lights beside the vanity mirror come on when the ignition switch is either in the "ACC" or "ON" position and the mirror cover is opened.

Glove compartment

⚠ CAUTION

Always keep the glove compartment closed while driving to reduce the risk of injury in the event of sudden stops or an accident.

