


When leaving the vehicle, make sure the light is turned off to avoid battery discharge.

### **Luggage area light (Wagon only)**



The luggage area light switch has three positions:

**ON:** The light stays on continuously.

**DOOR:** The light comes on only when the rear gate is opened.

**OFF:** The light stays off.

When leaving your vehicle, make sure the light is turned off to avoid battery discharge.