
Interior equipment

The storage tray is located under the floor of the luggage compartment and can be used to store small items. To open the lid, pull the handle up.

NOTE

When storing a flat tire, put the storage tray in the luggage compartment.

Maintenance tools





Your vehicle is equipped with the following maintenance tools:

Screwdriver

Wheel nut wrench