


4. Schematic



B4M1227B

- |   |  |                                |
|---|--|--------------------------------|
| (1) ABS control module and hydraulic control unit (ABSCM&H/U) | (9) Front right outlet solenoid valve            | (17) ABS warning light         |
| (2) ABS control module area                                   | (10) Rear left inlet solenoid valve              | (18) Stop light switch         |
| (3) Valve relay   | (11) Rear left outlet solenoid valve             | (19) Stop light                |
| (4) Motor relay   | (12) Rear right inlet solenoid valve             | (20) G sensor (only AWD model) |
| (5) Motor   | (13) Rear right outlet solenoid valve            | (21) Front left ABS sensor     |
| (6) Front left inlet solenoid valve                           | (14) Transmission control module (only AT model) | (22) Front right ABS sensor    |
| (7) Front left outlet solenoid valve                          | (15) Diagnosis connector                         | (23) Rear left ABS sensor      |
| (8) Front right inlet solenoid valve                          | (16) Data link connector                         | (24) Rear right ABS sensor     |

**MEMO:**