BODY ELECTRICAL SYSTEM (KEYLESS ENTRY)

1. Precaution

A: SUPPLEMENTAL RESTRAINT SYSTEM "AIRBAG"

Airbag system wiring harness is routed near the keyless entry control module.

CAUTION:

- All airbag system wiring harness and connectors are colored yellow. Do not use electrical test equipment on these circuits.
- Be careful not to damage airbag system wiring harness when servicing the keyless entry control module.

2. Pre-inspection

A: POWER DOOR LOCK

2A1: CHECK POWER DOOR LOCK.

Perform lock and unlock with door lock switch.

CHECK : Does the power door lock function normally?

(YES) : Go to step 2B1.

Repair power door lock. <Ref. to 6-2 [W1800].>

B: TRANSMITTER

2B1: CHECK TRANSMITTER BATTERY.

1) Remove battery from transmitter.

NOTE:

To prevent static electricity damage to transmitter printed circuit board, touch steel area of building with hand to discharge static electricity carried on body or clothes before disassembling transmitter.

