1. General Description 5140001

A: CAUTION S140001A03

• Wear working clothing, including a cap, protective goggles, and protective shoes during operation.

• Remove contamination including dirt and corrosion before removal, installation or disassembly.

• Keep the disassembled parts in order and protect them from dust or dirt.

• Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.

• Be careful not to burn your hands, because each part on the vehicle is hot after running.

• Be sure to tighten fasteners including bolts and nuts to the specified torque.

• Place shop jacks or safety stands at the specified points.

• Before disconnecting electrical connectors of sensors or units, be sure to disconnect ground cable from battery.