

SERVICE BULLETIN

APPLICABILITY ALL SUBARU VEHICLES

DATE

06-06-97

SUBJECT TIE DOWN PROCEDURES TO PREVENT ENGINE DAMAGE

When any Subaru vehicle is tied down, it is required that the transmission be left in neutral with the emergency brake firmly applied. The vehicle is to be kept in neutral during transportation.

Please ensure all necessary personnel are informed of this important information.