

3. Cruise Control System

A: WIRING DIAGRAM

Refer to "Cruise Control System" in the wiring diagram. <Ref. to WI-88, WIRING DIAGRAM, Cruise Control System.>

B: INSPECTION

Refer to CRUISE CONTROL SYSTEM (DIAGNOSIS). <Ref. to CC(diag)-11, Diagnostics with Phenomenon.>

C: NOTE

For operation procedures of each component of the cruise control system, refer to the respective section.

- Cruise control unit:<Ref. to CC-6, Cruise Control Module.>
- Cruise control command switch:<Ref. to CC-7, Cruise Control Command Switch.>
- Combination meter:<Ref. to CC-11, Combination Meter.>
- Stop light & brake switch:<Ref. to CC-12, Stop Light & Brake Switch.>
- Clutch switch:<Ref. to CC-13, Clutch Switch.>
- Inhibitor switch:<Ref. to CC-14, Inhibitor Switch.>
- Transmission control module (TCM):<Ref. to CC-15, Transmission Control Module (TCM).>
- Neutral position switch:<Ref. to CC-16, Neutral Position Switch.>