


# Harness Components Location

## WIRING SYSTEM

### 57. Harness Components Location

#### A: LOCATION


##### 1. SEDAN MODEL



WI-25606

- |                                     |                            |                             |
|-------------------------------------|----------------------------|-----------------------------|
| (1) Front wiring harness            | (6) Rear door cord RH      | (11) Front door cord LH     |
| (2) Engine wiring harness           | (7) Rear wiring harness RH | (12) Transmission cord      |
| (3) Bulkhead wiring harness         | (8) Roof cord              | (13) Oxygen sensor cord     |
| (4) Instrument panel wiring harness | (9) Trunk lid cord         | (14) Rear wiring harness LH |
| (5) Front door cord RH              | (10) Rear door cord LH     | (15) Fuel cord              |

## 2. OUTBACK MODEL



WI-25607

- |                                     |                            |                             |
|-------------------------------------|----------------------------|-----------------------------|
| (1) Front wiring harness            | (6) Rear door cord RH      | (11) Front door cord LH     |
| (2) Engine wiring harness           | (7) Rear wiring harness RH | (12) Transmission cord      |
| (3) Bulkhead wiring harness         | (8) Roof cord              | (13) Oxygen sensor cord     |
| (4) Instrument panel wiring harness | (9) Rear gate cord         | (14) Rear wiring harness LH |
| (5) Front door cord RH              | (10) Rear door cord LH     | (15) Fuel cord              |