


Electrical Component Location

TIRE PRESSURE MONITORING SYSTEM (DIAGNOSTICS)

3. Electrical Component Location

A: LOCATION



TPM00107

(1) TPMS & keyless entry CM
(4 door model)

(3) TPMS CM
(5 door model with push button
start)

(5) Snap-in type transmitter

(2) TPMS & keyless entry CM
(5 door model without push button
start)

(4) Tire pressure warning light