## **10.Clear Memory Mode**

## **A: OPERATION**

For operation procedures, refer to the "PC application help for Subaru Select Monitor".

## NOTE:

Clear the DTC stored in the airbag control module after repairing the airbag system.