

## 1. General Description

### A: SPECIFICATION

Refer to "Body Repair Manual" for general description of body structure, reference points and reference dimensions.

# INSTRUMENTATION/DRIVER INFO



---

	<b>Page</b>
1. General Description .....	2
2. Relay and Fuse .....	6
3. Combination Meter System .....	7
4. Clock System .....	21
5. Combination Meter .....	25
6. Speedometer .....	32
7. Tachometer .....	33
8. Fuel Gauge .....	34
9. ECO Gauge .....	35
10. Engine Coolant Temperature Gauge .....	36
11. Multi Display .....	37
12. Steering Switch .....	39