

## 4. Audio


### A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the center panel assembly.

#### CAUTION:

**Do not put your finger on the fin of the air vent grille. Doing so may damage the fin.**


- (1) Attach the protective tape (a) to the meter visor.



# Audio


## ENTERTAINMENT

- (2) Insert a finger into the air vent grille and release the left and right clips at the top of the center panel.  
(A), (B)
- (3) Insert a finger into the air vent grille and release the left and right clips at the center of the center panel.  
(C), (D)
- (4) Release the clips at the bottom of the center panel and remove the center panel assembly.



### 3) Remove the audio assembly.

- (1) Remove the left and right screws, and partially pull the audio out from center console.
- (2) Disconnect the connectors, and remove the audio assembly.



## B: INSTALLATION

Install each part in the reverse order of removal.