

Read Diagnostic Trouble Code (DTC)

EyeSight (DIAGNOSTICS)

8. Read Diagnostic Trouble Code (DTC)

A: OPERATION

For operation procedures, refer to the “PC application help for Subaru Select Monitor”.

NOTE:

For details concerning DTC, refer to “List of Diagnostic Trouble Code (DTC)”. <Ref. to ES(diag)-78, List of Diagnostic Trouble Code (DTC).>