6. Switches and Harness

A: NOTE

1. P-CR OFF & LANE OFF SWITCH

The P-CR OFF & LANE OFF switch is integrated in the stereo camera cover assembly. If the P-CR OFF & LANE OFF switch is faulty, replace the stereo camera cover assembly. <Ref. to ES-8, Stereo Camera.>

B: INSPECTION

1) Remove the stereo camera cover assembly.

2) Check the resistance between the terminals of P-CR OFF switch or LANE OFF switch.

• P-CR OFF switch

Terminal No.	Inspection conditions	Standard	Connector Sketch
	OFF	1 M Ω or more	
11 — 12	ON	Less than 1 Ω	7654321 1615141312111098 Φ

• LANE OFF switch

Terminal No.	Inspection conditions	Standard	Connector Sketch
	OFF	1 M Ω or more	
10 — 12	ON	Less than 1 Ω	7654 121 1615141312111098 Φ Φ Φ ADA00462

3) If the result of the inspection is not within the standard value, replace the stereo camera cover assembly.