

## **Read Diagnostic Trouble Code (DTC)**

KEYLESS ACCESS WITH PUSH BUTTON START SYSTEM (DIAGNOSTICS)

---

### **7. Read Diagnostic Trouble Code (DTC)**

#### **A: OPERATION**

For operation procedures, refer to the “PC application help for Subaru Select Monitor”.