

Clear Memory Mode

LAN SYSTEM (DIAGNOSTICS)

8. Clear Memory Mode

A: OPERATION

For details of operation procedures, refer to “PC application help for Subaru Select Monitor”.