


Electrical Component Location

OCCUPANT DETECTION SYSTEM (DIAGNOSTICS)

4. Electrical Component Location

A: LOCATION



- (1) Airbag ON/OFF indicator light
- (2) Occupant detection control module

(3) Occupant detection sensor

(4) Buckle switch (passenger's seat)