



30. Navigation System

A: WIRING DIAGRAM



1. MODEL WITH STANDARD NAVIGATION



WI-41364

Navigation System

WIRING SYSTEM



WI-41365








Navigation System

WIRING SYSTEM

NAVI-03

NAVI-03

- ★1 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2 AND 3
- ★2 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 4, 5 AND 12
- ★3 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 6, 7 AND 8
- ★4 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 9, 10 AND 11












WI-41366

Navigation System

WIRING SYSTEM



2. MODEL WITH PREMIUM NAVIGATION



WI-41367

Navigation System

WIRING SYSTEM




WI-41368

Navigation System

WIRING SYSTEM

NAVI(P)-03

NAVI(P)-03








WI-41369

Navigation System

WIRING SYSTEM

NAVI(P)-04

NAVI(P)-04








WI-41370

Navigation System

WIRING SYSTEM

NAVI(P)-05

NAVI(P)-05



WI-41371