


Airbag System

WIRING SYSTEM

5. Airbag System

A: WIRING DIAGRAM




WI-41316

Airbag System

WIRING SYSTEM

A/B-02

A/B-02



i10

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40



WI-36143

Airbag System

WIRING SYSTEM

A/B-03



A/B-03



WI-36144

Airbag System


WIRING SYSTEM



WI-36145

Airbag System

WIRING SYSTEM



WI-36146