27.AUX Input Terminal

A: REMOVAL

1. REAR ENTERTAINMENT INPUT TERMINAL

- 1) Disconnect the ground cable from the battery.
- 2) Remove the left rear quarter trim lower. <Ref. to EI-45, REMOVAL, Rear Quarter Trim.>
- 3) Remove the AUX input terminal from the rear quarter trim.

2. AUDIO INPUT TERMINAL

- 1) Disconnect the ground cable from the battery.
- 2) Remove the console box. <Ref. to EI-38, RE-MOVAL, Console Box.>
- 3) Remove the AUX input terminal from the console box.

B: INSTALLATION

Install in the reverse order of removal.