

16.Center Console

A: REMOVAL

- 1) Remove the control panel. <Ref. to AC-32, RE-MOVAL, Control Panel.>
- 2) Remove the instrument panel lower cover. <Ref. to EI-36, REMOVAL, Instrument Panel Lower Cover.>
- 3) Remove the glove box. <Ref. to EI-37, REMOV-AL, Glove Box.>
- 4) Remove the console box. <Ref. to EI-38, RE-MOVAL, Console Box.>
- 5) Remove the screws and clips (A) to remove the console side panel upper.
- · Driver's side



· Passenger's side



B: INSTALLATION

Install in the reverse order of removal.