


5. Front Grille

A: REMOVAL

- 1) Remove the front bumper. <Ref. to EI-21, REMOVAL, Front Bumper.>
- 2) Remove the screws, and remove the front grille from bumper face.



B: INSTALLATION

Install in the reverse order of removal.