


FUSE & RELAY INFORMATION

Fuse & Relay Information (3)

SD100-3

E/R Fuse & Relay Box



⊗ USE THE DESIGNATED FUSE AND RELAY ONLY

NO.	RELAY NAME	TYPE
CHG90	Wiper FRT, LO Relay	Plug Micro(5P)
CHG92	C/FAN HI Relay	Plug Micro(4P)
CHG93	Deicer Relay	Plug Micro(4P)
CHG94	ATM P/N Relay	Plug Micro(5P)
CHG95	Blower Relay	Plug Micro(4P)
CHG96	Horn Relay	Plug Micro(4P)
CHG97	C/FAN LO Relay	Plug Micro(4P)
CHG98	Start Relay	Plug Micro(4P)
CHG99	B/A Horn Relay	Plug Micro(4P)
CHG100	RR HTD Relay	Plug Micro(4P)

ELMSD10100CN