For JBS Units without On-board Door Lock Relays:

Requires
(1)778 or
(2) 775's



For JBS Units with On-board Door Lock Relays:



NOTE: Connect the **RED WITH BLACK STRIPE** wire to ground.

KE-100, KE-150 and 1702