

Engine & Cooling

Fuel

Ignition

Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system1.3 MPi 12V CAT1992 to 1997

Type		4G13-2 SOHC 12V 55kW
Capacity (cm³) / number of cylinders		1298 / 4
Compression ratio / pressure	bar	9.5 / 14.2
Oil pressure	bar	≥0.76
Oil temperature	°C	—
Valve clearance - inlet	mm	0.15 H
Valve clearance - exhaust	mm	0.25 H
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	88
Radiator cap pressure	bar	0.76 to 1.04

Fuel system1.3 MPi 12V CAT1992 to 1997

Idle speed - manual [auto]	rpm	750±50
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.5 N/A
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO2 @ idle speed [3000 rpm] - see page VI	%	—
O2 @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		Mitsubishi
Type / ref		ECI Multi MPI
Main jet / needle		—
Injection pressure	bar	2.6
Pump pressure	bar	3.3 to 3.5
Octane rating	RON	95[U]

Ignition system1.3 MPi 12V CAT1992 to 1997

Type		Electronic
Ignition coil		In distributor
Primary resistance	ohms	0.9 to 1.2
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		Mitsubishi
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		Clockwise
Ignition timing - basic [static	° Crankshaft @ rpm	5±2 BTDC @ 750±100
V = Vacuum NV = No Vacuum		V
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		NGK
Type		BPR5ES-11
Electrode gap	mm	0.70 to 0.80

Electrical system1.3 MPi 12V CAT1992 to 1997

Battery	V / CC / RC	12 / 50Ah
Alternator voltage / full load current / engine rpm		13.4 to 14.9 / 65 / 2500
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear1.3 MPi 12V CAT1992 to 1997

Brakes -		
Front (min. friction material thickness)	mm	2.0
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	155x13
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	1.7 / 1.8
- Estate / Van	bar	—

Front suspension / wheel alignment

Toe-in (+) / Toe-out (–)	mm [°]	0±1.5
Camber		0±30'
Castor		+1°6'±30'
King pin inclination		—

Rear suspension / wheel alignment

Toe-in (+) / Toe-out (–)	mm [°]	0
Camber		-40'±35'


Torque wrench settings1.3 MPi 12V CAT1992 to 1997

Cylinder head - stage 1	Nm	70 to 75 C
- stage 2	Nm	80 to 85 H
Cylinder head - stage 3	Nm	—
- stage 4	Nm	—
Big-end bearings	Nm	32 to 35
Main bearings	Nm	50 to 55
Clutch cover	Nm	15 to 22
Flywheel [driveplate]	Nm	130 to 140
Front hubs	Nm	WSM
Rear hubs	Nm	79 to 98
Wheel nuts / bolts	Nm	80
Spark plugs	Nm	20 to 30


Capacities1.3 MPi 12V CAT1992 to 1997

Engine oil & filter	litres	3.4
Gearbox - 4-speed [5-speed]	litres	2.1
Automatic transmission - refill	litres	—
Final drive	litres	WT
Cooling system	litres	5.0
Fuel tank	litres	45

Notes and Illustrations



1298 cm³, 12V



1298 cm³, 12V