


Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling systemLaguna 2.0i (B56C/H/N)1994 to 1997

Type		F3R-7-23/-7-22 85kW SOHC 8V
Capacity (cm³) / number of cylinders		1998 / 4
Compression ratio / pressure	bar	9.8 / _
Oil pressure	bar	1.2 [3.5]
Oil temperature	°C	80
Valve clearance - inlet	mm	0.20
Valve clearance - exhaust	mm	0.40
Firing order		1-3-4-2
No 1 cylinder position		FE
Thermostat opening temperature	°C	89
Radiator cap pressure	bar	1.2

Fuel systemLaguna 2.0i (B56C/H/N)1994 to 1997

Idle speed - manual [auto]	rpm	830±50 [750±50] N/A
Fast idle speed - manual [auto]	rpm	_
CO @ idle speed [3000 rpm] - see page VI	%	≤0.3 N/A
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO2 @ idle speed [3000 rpm] - see page VI	%	_
O2 @ idle speed [3000 rpm] - see page VI	%	_
Carburettor / fuel injection		_Siemens Bendix
Type / ref		MPI
Main jet / needle		_
Injection pressure	bar	2.5±0.2
Pump pressure	bar	3.0±0.2
Octane rating	RON	95[U]

Ignition systemLaguna 2.0i (B56C/H/N)1994 to 1997

Type		Computerized
Ignition coil		_
Primary resistance	ohms	0.4 to 0.8
Ballast resistor	ohms	_
Voltage - Tmnl 15(+) to earth	V	_
Distributor		_
Points gap (air gap)	mm	_
Dwell angle	° (%)	_
Condenser capacity	µF	_
Rotation		_
Ignition timing - basic [static	° Crankshaft @ rpm	Computer control N/A
V = Vacuum NV = No Vacuum		_
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	_
Spark plugs		_/Bosch/Champion
Type		W7DCO / N7YCX
Electrode gap	mm	0.75 to 0.85

Electrical systemLaguna 2.0i (B56C/H/N)1994 to 1997

Battery	V / CC / RC	12V 50/60AH
Alternator voltage / full load current / engine rpm		13.5/110
Starter motor current / voltage - cranking	A / V	_
- locked	A / V	_

Running gearLaguna 2.0i (B56C/H/N)1994 to 1997

Brakes -		
Front (min. friction material thickness)	mm	6.0 with backing
Rear (min. friction material thickness)	mm	6.0 with backing

Tyres		
Saloon	Size	185/65x14:195/65x14:205/60x15
Estate / Van	Size	185/65x14: 195/65x14
Pressure - front / rear - Saloon	bar	2.3 / 2.3. 205: 2.5 / 2.3
- Estate / Van	bar	Refer to vehicle

Front suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	1.0±1.0	Est: -1.0±1.0
Camber		-9'±30'	
Castor		3°±30'	Est: 4°±30'
King pin inclination		11°52'±30'	

Rear suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	-3.0±1.0
Camber		-1°15'±10'


Torque wrench settingsLaguna 2.0i (B56C/H/N)1994 to 1997

Cylinder head - stage 1	Nm	30
- stage 2	Nm	+ 50±4°
Cylinder head - stage 3	Nm	Wait 3 mins, then -180°
- stage 4	Nm	25 + 123±7°
Big-end bearings	Nm	45 to 50
Main bearings	Nm	60 to 65
Clutch cover	Nm	26 to 28
Flywheel [driveplate]	Nm	50 to 55
Front hubs	Nm	250
Rear hubs	Nm	190
Wheel nuts / bolts	Nm	90 to 100
Spark plugs	Nm	20 to 30

CapacitiesLaguna 2.0i (B56C/H/N)1994 to 1997

Engine oil & filter	litres	5.5
Gearbox - 4-speed [5-speed]	litres	3.1
Automatic transmission - refill	litres	3.5
Final drive	litres	WT. AT: 1.0
Cooling system	litres	9.0
Fuel tank	litres	66

Notes and Illustrations



1998 cm³, 8V