



Position of Parts in Instrument Panel <RHD>




- H 26 Headlight Dimmer Switch Assembly
- H 27 Windshield Wiper Switch Assembly
- H 28 Windshield Wiper Switch Assembly
- H 29 Steering Sensor
- H 30 Spiral Cable Sub-Assembly
- H 31 Spiral Cable Sub-Assembly
- H 33 Pre-Crash System Cancel Switch Assembly
- H 34 No. 1 Interior Illumination Light Assembly RH
- H 35 Turn Signal Flasher Assembly
- H 36 Outer Mirror Heater Switch Assembly
- H 38 Outer Mirror Switch Assembly
- H 39 Back Sonar or Clearance Sonar Switch Assembly
- H 40 Light Control Rheostat
- H 41 Headlight Cleaner Switch Assembly
- H 42 Steering Heater Switch
- H 43 Fuel Lid Opener Switch
- H 44 DLC3
- H 45 Spiral Cable Sub-Assembly
- H 46 Radio Setting Condenser
- H 47 Radio Receiver Assembly
- H 48 Radio Receiver Assembly
- H 49 Radio Receiver Assembly
- H 50 Radio Receiver Assembly

Position of Parts in Instrument Panel <RHD>


H 26
Black




H 27
White




H 28
White




H 29
White



H 30
Black




H 31
Yellow




H 33
White




H 34
Gray




H 35
White




H 36
Black




H 38
Black




H 39
Black




H 40
White




H 41
Gray




H 42
Black




H 43
Black



H 44
White




H 45
Black




H 46
White



H 47
White



H 48
White



H 49
White

