


# Position of Parts in Engine Compartment <LHD>


- \* 1:LED Headlight
- \* 2:Halogen Headlight
- \* 3:Halogen Fog Light
- \* 4:LED Fog Light




- A 36 Rear Washer Motor & Pump Assembly
- A 37 Level Warning Switch Assembly
- A 38 Headlight Assembly RH
- A 40 Headlight Assembly RH
- A 41 Headlight Assembly RH
- A 42 Headlight Cleaner Motor and Pump Assembly
- A 43 Cleaner Control Relay
- A 44 Front Airbag Sensor RH
- A 45 Engine Hood Courtesy Switch
- A 59 Front Wiper Deicer (Windshield Glass)
- A 60 ECM
- A 61 Skid Control ECU with Actuator Assembly
- A 62 Inverter Assembly with Converter
- A 66 Option Connector
- A 73 Headlight Assembly LH
- A 75 Headlight Assembly RH
- A 76 Headlight Assembly LH
- A 77 Headlight Assembly RH
- A 79 Front Fog Light Assembly LH
- A 80 Front Fog Light Assembly RH
- A 81 Water Pump Assembly with Motor
- A 82 Vehicle Approaching Speaker Assembly

# Position of Parts in Engine Compartment <LHD>

A 36  
Gray




A 37  
Black




A 38  
Gray



A 40  
Black




A 41  
Gray




A 42  
Black



A 43  
Gray



A 44  
Yellow




A 45  
Gray




A 59  
Black



A 60  
Black



A 61  
Gray



# Position of Parts in Engine Compartment <LHD>

