























Position of Parts in Instrument Panel <From Aug. 2009 Production>



E 53	Foot Lamp (LH)
E 54	Foot Lamp (RH)
E 55	Light Control Rheostat
E 56	Luggage Compartment Door Opener SW
E 57	Luggage Compartment Door Opener SW (Main)
E 58	Main Body ECU
E 59	Main Body ECU
E 60	Main Body ECU
E 61	Main Body ECU
E 65	Outer Mirror Control ECU
E 66	Outer Mirror Control ECU
E 67	Outer Mirror SW
E 68	Power SW
E 69	Radio Receiver Assembly
E 70	Radio Receiver Assembly
E 75	Rear Sunshade SW
E 76	Retractable Outer Mirror SW
E 77	Shift Lock Control ECU
E 78	Steering Lock ECU
E 79	Tilt and Telescopic ECU
E 80	Tilt Motor
E 84	Transmission Control SW
E 85	Turn Signal Flasher
E 86	Tweeter (Instrument Panel LH)
E 87	Tweeter (Instrument Panel RH)
E 88	Yaw Rate Sensor
E 89	Headlamp Cleaner SW
E 90	Diode (Interior Light)
E 91	Junction Connector
E 92	Junction Connector
E 93	VSC Warning Buzzer
E 94	Speaker (Instrument Panel LH)
E 95	Speaker (Instrument Panel RH)
E 97	Telematics Transceiver
E 98	Mayday Battery
E 99	Pre-Crash System Cancel Switch Assembly
E 101	Multi-Media Interface ECU Assembly
E 102	Multi-Media Interface ECU Assembly
E 103	Radio Receiver Assembly
E 104	Display & Navigation Module Display
E 105	Display & Navigation Module Display
E 106	Display & Navigation Module Display
E 107	Display & Navigation Module Display
E 108	Display & Navigation Module Display
E 109	Radio Receiver Assembly
E 110	Radio Receiver Assembly
E 111	Display & Navigation Module Display
E 112	Telematics Transceiver
E 113	Multi-Media Interface ECU Assembly
E 114	Display & Navigation Module Display
E 115	IEEE Connector
E 116	Junction Connector
E 117	Junction Connector
E 118	Display & Navigation Module Display
E 120	Electrical Key Oscillator (Console)

Position of Parts in Instrument Panel <From Aug. 2009 Production>



Position of Parts in Instrument Panel <From Aug. 2009 Production>

